

## External Insulation

Material: [Wood fibre].

Supplier: [BACK TO EARTH (SW) LTD, 7 Tuns Lane, Silverton, Devon. EX5 4HY, Tel:- 01392 861763]

- Product reference: [UdiRECO Woodfibre insulation].

Thickness: 120mm.

Preparation: Loose render to be removed and, if in small 'patches' to be replaced with similar. Brush walls down using a stiff brush ensuring that the surface is stable and able to take mechanical fixings.

Installation requirements:

- Insulation boards fixed using UdiASSEMBLY Masonry Fixings for 120mm UdiRECO, 8no. fixings per board.

- Install in accordance with manufacturers recommendations.

- Service installations: run services up rear of insulation in plastic conduits or chase conduit into hard fibre layer of board.

Finishes:

- 1no. layer of 5mm UdiFOUNDATION COAT lime based render with UdiREINFORCEMENT mesh inlaid into render layer.

- 1no. coat of UdiPERL Primer. Apply with brush or roller as per manufacturers recommendations.

- 2-3 mm layer of UdiPERL 1.5mm fine finish render.

REFER TO MANUFACTURERS GUIDANCE AND PRODUCT DATA SHEETS IN APPENDIX FOR FULL PRODUCT INFORMATION AND INSTALLATION REQUIREMENTS.