

## Assembly Instruction

### Functioning

- The FID can be set in the insulating board with a cordless screwdriver or by hand.
- For thick layers of plaster a pre-drilling (6 mm) is recommended.
- The special spiral thread taps itself in the insulating board.
- Fixtures are fixed with a 4 to 4.5 mm screw for the FID 50.
- Water ingress in the insulation can be prevented by sealing the plug collar with a suitable sealant after successful pre-positioned installation.

